A5000 Series

Communication Functions User's Manual

1. Overview

This manual explains the specifications of the communication functions provided by the A5000 series of digital panelmeters. It also explains how to handle the A5000 series.


2. Specification

	RS-232C	RS-485
	(Compatible with EIA RS-232C)	(Compatible with EIA RS-485)
Synchronization		Start-stop
Communication method	Full-duplex	Two-wire half-duplex (polling/selecting)
Transmission rate	38400bps / 19	0200bps / 9600bps (default) / 4800bps / 2400bps
Number of start bits		1bit
Data length		7bit (default) / 8bit
Error detection	Even	parity (default) / odd parity / no parity
(parity bits)		Block check character (BCC) checksum
Number of stop bits		1bit / 2bit (default)
Character code		ASCII
Transmission control procedure		Non-procedural
Signal name used	TXD、RXD、SG	Non-inverting (+), inverting (-)
Number of units that can be connected	1 unit	Max 31 units
Transmission line length	15m	500 m max. (overall length)
		* In CE conformity, it is under 30m
Delimiter		CR+LF (default) / CR

3. Terminal description and connection method

The communication connector of the A5000 series is a modular jack RJ-14(6P4C) compatible with the FCC68 standard. Use a modular plug RJ-14(6P4C) also compatible with the FCC68 standard when connecting the panelmeter.

3.1. Terminal Assignments




RS-232C		
Terminal No.	Name	Description
20	RXD	RS-232C Receive Data terminal
21	TXD	RS-232C Transmit Data terminal
22	NC	Do not connect.
23	SG	Common terminal for the communication functions (signal GND of the circuit)
		Turiculous (signal GND of the circuit)

RS-485		
Terminal No.	Name	Description
20	(+)	RS-485 Non-inverting output (+)
21	(-)	RS-485 Inverting output (-)
22	TERM	RS-485 terminator enable pin
23	SG	Common terminal for the communication functions (signal GND of the circuit)
* Shorting	between tern	ninals 21 and 22 enables the terminator 200 Ω .

^{*} Do not connect the shields wire to the SG terminal.


3.2. Example of RS-232C Connection



Note: The above-illustrated connection of the CTS and RTS terminals on the host side is only a typical example for hardware control. Consult your system designer for further details on how to cope with the terminals.

3.3. Example of RS-485 Connection

If the panelmeter is positioned to be an end station as the result of an RS-485 connection, short-circuit terminals 21-22 to enable the terminator.



4. Communication Function Parameters

The baud rate, data length, parity bit, stop bit, delimiter, and device ID (RS-485 only) are the user-selectable parameters of the communication functions provided by the A5000 panelmeter.

For details on how to set the parameters, see the user's manual of the A5000 main unit.

5. RS-485 Transmission/Reception Formats

5.1. Establishing and Releasing Communication Link


Functions / Description	Transmit Data Received Data	
	1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 Length 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 Length 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22	Length
Establishment of communication Link	ENQ 0 1 CR LF 2 ACK 0 1 CR LF	2
·Shift to command acceptance state of module.	* Set a two-digit number as the device ID (00 is void). (There is no response when the device ID is different, and released if communication is established.)	
	(If the first data is EN and communication is established when a command error occurs, it is released.)	, ,
	* Normal response. Response time: 20 ms max.	
*Release of communication.	[eot] GR LF	
	* Communication is still possible when another device ID is specified without releasing the communication link. (No response is made for release.)	
	(If the first data is EN and communication is established when a command error occurs, it is released.)	

5.2 Available control codes

Control Code	Hexadecimal	Name	Description
STX	02H	Start of Text	Marks the starting point of text.
ETX	03H	End of Text	Marks the ending point of text.
EOT	04H	End of Transmission	Marks the end of transmission.
ENQ	05H	Enquiry	Denotes an enquiry.
ACK	06H	Acknowledge	Denotes an affirmative reply.

5.3 BCC Checksum

As a means of error detection, a block check character (BCC) checksum is added to the RS-485 communication function of the A5000 panelmeter. See the following illustrations for details on the transmission and reception formats (which are as illustrated in the table of communication commands in Section6 for the RS-232C communication function).



6. Communicate Command

Functions/ Description		nsmi			_	_														Received Data	
		2				6	7	8 9	10	11	12 13	14	15 1	6 17	18 1	9 20	21 2	2 23	Length		_ength
Measured value and comparison results response	D	S	Р	CR	LF														3	(+5000 reading, without decimal point, response when judgment result is HL)	10
response																					10
																				(-5000 reading, without decimal point, response when judgment result is HI.)	
																				(500.0 reading, with decimal point, response when judgment result is HL)	11
																					10
																				(+ over reading, without decimal point, response when judgment result is HI.)	
																					11
																				(- over reading, with decimal point, response when judgment result is HI.) P H 5 0 0 0 H I CR LF	10
																				(Peak hold reading, without decimal point, response when judgment result is HI.)	
																				1~2 characters : Normally 2 blank characters. "<=" for over reading. After 3 characters : Reading value & comparison result. Right justified when there are fewer digits.	
																				After 3 characters : Reading value & comparison result. Right justified when there are fewer digits. There is a space between the reading value and the comparison result.	
																				No response is returned if this is the configuration mode.	
																				During HOLD or simple average calculation, it responds after the simple average calculation is completed	
																				(After the reading value is calculated). If another command is sent or received while waiting for a response, there is no response.	
																				When "over value", the last calculated reading value is returned.	
																				Responds after indication update.	
Measured value response		_	•	0.0	LF	\vdash	\dashv	-	-	₩	_	-	-	-	⊢⊢	-	-	-	3	OR LF	12
* Peak hold, other measurement states	IVI	-	3	GR	LF														3	(0 reading, without decimal point.)	12
and comparison results do not respond.																					12
																				(0.01 reading, with decimal point.)	12
																				- 1	12
																				- 0 . 0 0 5 CR LF	12
																				(-0.005 reading, with decimal point.)	40
																				< =	12
																				(over reading, with decimal points)	
						1 1														1~2 characters : Normally 2 blank characters. "<=" for over reading.	
																				3 characters : Polarity indication at the maximum number of characters. If there is no polarity at the maximum character, it is blank.	
																				4~12 characters : Reading value. If there are fewer characters, it is left justified. The remaining	
																				characters are blank.	
																				In the case of the configuration mode or during hold, the last calculated reading value is responded.	
																				If no calculation has been performed, the reading value is 0 (including cases with a decimal point). When "over value", the last calculated reading value is returned.	
																				*	
Judgment (Comparison) result response	J	G	М	CR	LF	П	П												3		15
* Measurement status does not respond.																				(Response when the judgment result is HI.) G O CR LF	15
																				(Response when the judgment result is GO.)	13
																					15
																				(Response when the judgment result is LO.) NO ? CR LF	5
																				N O ? CR LF	5
																				1 ~ 15 characters : The remaining characters are blank. In the case of the configuration mode, the last calculated comparison result is responded.	
																				In the case of the configuration mode, the last calculated comparison result is responded.	
Hold remote control response					\vdash	П															
· Checking hold control status via	s	Т	Н	CR	LF														3		6
Communication.																				(Response when there is no remote control or when the remote control's hold status is OFF.) H O L D CR LF	6
																				(Response when hold state is ON by remote control.)	U
Hold terminal response						1 1															
 External control terminal status response. 	E	S	A	CR	LF														3	S T A R T CR LF (Response in hold OFF state.) * Note that this is the terminal state, not the hold state.	6
																					6
																				(Response in hold ON state.)	
Hold Remote Control •Remote status OFF command via		т				CR	LF												5	Y E S CR LF	5
Communication.		(Hole			3	CR	LF												5	(Received instructions)	5
	1	Ĺ																		* Instructions are not accepted in the case of the configuration mode or shift configuration mode ("NO ? " Respons	
•Remote status ON command via		Т			Н	CR	LF												5		5
Communication.	;	(Hole	4 ON	1)		, 1														(Received instructions) * Instructions are not accepted in the case of the configuration mode or shift configuration mode ("NO?" Respons	(020
																				→ BISLUCIONS are not accepted in the case of the configuration mode or shift configuration mode (NO ? Mespons	150).
Trigger input	Т	CR	LF																1		11
																				(+500.0 reading, with decimal point) * The response is the same as the "DSP".	
																				* No response when the hold status is not ON (by remote or external control).	
Hold remote control cancellation	E	S	м	CR	LF														3		5
	Е	s	М	CR	LF														3		5

Functions/ Description	Tr	ansn	nit D	ata																	Received Data
	1	2	3	4	5	6	7	8	9 1	0 11	12	13 14	15	16 1	7 18	19	20 2	1 22	23	Length	1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 Length
Digital zero remote control response	_	-		C C	. l	.														3	D Z R O F F CR LF 7
 Checking the digital zero control status. 	0		-	Ci	R LF															3	(Response when digital zero configuration is OFF by remote, external control or key operation.)
																					D Z R 1 0 0 0 CR LF 9
																					(Response when digital zero configuration is ON by remote, external control or key operation.) * The main unit responds with the reading when the digital zero function is set to ON.
																					Right-justified zero suppressed response. Includes decimal point if any.
Digital zero terminal response	L_	L	١.																	_	
Checking the external control input terminal status.	E	Z	^	CF	R LF															3	D Z R O F F CR LF 7 (Response with the OFF status of the digital zero function.)
terriman status.																					* Note that this is a terminal state, not a configuration of digital zero function.
																					D Z R O N CR LF 6
																					(Response with the ON status of the digital zero function.) * Note that this is a terminal state, not a configuration of digital zero function.
Digital zero remote control																					
• Sets the digital zero function to ON.	D		F			N	CR	LF												6	Y E S CR LF 5
* Digital zero is the reading value after control.		(DI	gitai	zero	ON.)		1 1	1	-				1 1		1			1 1			(Received instructions) * Instructions are not accepted in the case of the configuration mode or shift configuration mode ("NO?" Response).
																					When the digital zero backup function is ON by remote control, the digital zero configuration is
0. 11 5.11 6 15 1 055	_	-	F		0	F	F													7	memorized when the power is turned off. Y E S CR LF 5
 Sets the digital zero function to OFF. 	0				OFF.		, ,	CR	LF ;	i	1 1	•	1 1	•	•	1 1	•	1 1		,	(Received instructions)
																					* Instructions are not accepted in the case of the configuration mode or shift configuration mode ("NO ?" Response).
																					The control state will not be memorized when the remote OFF Instructions is transmitted (the remote OFF Instructions is also cancelled). "SAV" is Necessary.
																					OFF instructions is also cancelled). SAV is Necessary.
	D		F				0													8	YES CR LF 5
												ot accep				ONSE)).				(Received instructions) * Instructions are not accepted in the case of the configuration mode or shift configuration mode ("NO ? " Response).
		* [ert ji	JSTITIE	ea wr	nen tn	ere are	e rewe	er chai	racters.	Decim	al points	are n	ot inclu	ded.	1 1		1 1			* Instructions are not accepted in the case of the configuration mode or shift configuration mode (NO ? Response). When the digital zero backup function is ON by remote control, the digital zero configuration is
																					memorized when the power is turned off.
 Digital zero remote control cancellation. 	. E	Z	N	C	R LF															3	Y E S CR LF 5 (Received instructions) "SAV" is Necessary if you want to continue even after restarting the power.
Digital zero value OFF instruction save	╁	\vdash	+	+	+	+	\vdash	-	_	-	\vdash	-	+	-	+	H	-	+	+		(Received instructions) SAY is Necessary if you want to continue even after restarting the power.
Storage of digital zero values.		A	٧	CF	R LF	-														3	Y E S CR LF 5
* The digital zero backup function must be	•																				(Received instructions)
ON.		Wh	en tr	i ansm	i ittins	the [) DZR 0	FF an	d EZN	i Loomma	i i ands. vo	i ou must	transi	nit the	SAV″	comm	and to	1 1			* Instructions are not accepted in the case of the configuration mode or shift configuration mode ("NO?" Response). NO R LF 5
										restart t											(Response when digital zero backup configuration is OFF.)
Comparative output remote control response																					
 Checking of comparative output terminal simulated output status via communication. 	R	L	Y	CI	R LF															3	R L Y O F F CR LF 7 (Response when there is no remote control or when all terminals are OFF by remote control.)
simulated output status via communication.																					R L Y H I CR LF 6
																					(Response when HI terminal is ON via remote control.)
																					R L Y G O CR LF 6 (Response when GO terminal is ON via remote control.)
																					R L Y L O CR LF 6
																					(Response when LO termina is ON via remote control.)
 Comparison judgment HI ON instruction via communication. 	R				for H		CR	LF :	-	1				-	1		1			6	Y E S CR LF 5 (Received instructions)
* Values are GO, and LO in addition to		(36	ils it	Ü	iorn		1 1						1 1								* Instructions are not accepted in the case of the configuration mode or shift configuration mode ("NO?" Response).
the above.	R		Y				CR	LF												6	Y E S CR LF 5
		(Se	ts to	ON	for G	iO.)												1 1			(Received instructions) * Instructions are not accepted in the case of the configuration mode or shift configuration mode ("NO?" Response).
	R	L	Y		L	0	CR	LF												6	Y E S CR LF 5
		(Se	ts to	ÓΝ	for L	0.)			i			·			i						(Received instructions)
· All comparison output OFF instructions	P		V		0	F	F	CB												7	* Instructions are not accepted in the case of the configuration mode or shift configuration mode ("NO ?" Response). Y E S CR LF 5
via communication.							tputs 1													•	(Received instructions)
	_																				* Instructions are not accepted in the case of the configuration mode or shift configuration mode ("NO ?" Response).
Comparison output remote control Cancellation.	R	U	N	CF	R LF															3	Y E S CR LF 5 (Received instructions.)
Remote control response	\dagger	\vdash	+	+	\top	+		_											1		
· Checking of remote control status of	R	E	A	CF	R LF	:														3	N O ? CR LF 5
each function via communication.																					(Response with the status of every function not being remote-controlled.) D Z R CR LF 3
																					(Response with the status of the digital zero function being remote-controlled.)
																					P V H CR LF 3
																					(Response with the status of the peak hold function being remote-controlled.) S T H CR LF 3 3
																					(Response with the status of the hold function being remote-controlled.)
																					R L Y CR LF 3
																					(Response with the status of the comparison output function being remote-controlled) * The main unit responds with the statuses of functions by separating them with delimiters if
																					multiple functions are being remote-controlled. This does not include remote control with
	1-				\perp		Н	_	_	_	₩		Н		-	Н	_	44	_		"Key operation prohibition".
Peak hold remote control response The response contents will differ depending		٧	H	CF	R LF								H							3	P V H P H - O F F CR LF 10 (Response with the status of the peak hold function being set to OFF by remote control.)
on the condition data configuration.	1																				P V H V H - O F F CR LF 10
	1																				(Response with the status of the valley hold function being set to OFF by remote control.)
	1																				P V H P V - O F F CR LF 10 (Response with the status of the peak/valley hold function being set to OFF by remote control.)
	1													- 1							P V H P H - O N CR LF 9
	1													- 1							(Response with the status of the peak hold function being set to ON by remote control.)
	1																				P V H V H - O N CR LF 9 (Response with the status of the valley hold function being set to ON by remote control.)
	1																į				P V H P V - O N CR LF 9
- Deals hald have 11 1	_	-	١.																	•	(Response with the status of the peak/valley hold function being set to ON by remote control.)
·Peak hold terminal response	E	P	^	CF	R LF									Í						3	P V H O F F CR LF 7 (Response with the OFF status of the peak hold function) *Terminal status.
	1													- 1							PVHONCRLF6
	1													- 1							(Response with the ON status of the peak hold function) *Terminal status.
Peak hold type configuration	P	V	μ		P	н	CR	LF						- 1						6	Y E S CR LF 5
		(Se	ts to	the	peak	hold.))													-	* Instructions are not accepted in the case of the configuration mode or shift configuration mode ("NO ?" Response).
	Р						CR	LF						Í	-					6	Y E S CR LF 5
	Р					y hold	CR	LF !	1	1		1		1	1		1	1.1		6	* Instructions are not accepted in the case of the configuration mode or shift configuration mode ("NO?" Response). Y E S CR LF 5
		(Se	ts to	the	peak	valley	/ hold.)									, :				-	* Instructions are not accepted in the case of the configuration mode or shift configuration mode ("NO?" Response).
·Peak hold remote control	P	V (C	H		0	N	CR ction t	LF	,			1		1			1			6	Y E S CR LF 5
	Р						F F			1		1		1			1	1 1		7	* Instructions are not accepted in the case of the configuration mode or shift configuration mode ("NO?" Response). Y E S CR LF 5
		(Se	ts th	ере	ak ho	ld fun	ction t														* Instructions are not accepted in the case of the configuration mode or shift configuration mode ("NO?" Response).
·Peak hold value response	P	٧	D	CF	R LF									Í						3	P H 5 0 0 . 0 CR LF 10
	1													ĺ							(Response with the peak hold value.) V H
	1													- 1							(Response with the valley hold value.)
	1																				P V 6 0 0 . 0 CR LF 10
	1																				(Response with the peak/valley hold values.) Batch response with delimiters.
•Peak hold value clear	Р	С	L		Р	Н	CR	LF												6	Y E S CR LF 5
	_					hold v						-		- 1			- 1	1			* Instructions are not accepted in the case of the configuration mode or shift configuration mode ("NO?" Response).
	P						CR value.)	LF	i	1		1	1 1	1	1		1	1 1		6	Y E S CR LF 5 * Instructions are not accepted in the case of the configuration mode or shift configuration mode ("NO?" Response).
	Р	C	L		P	V	CR							1			1			6	Y E S CR LF 5
							hold v		.)			-		- 1			- 1	1			* Instructions are not accepted in the case of the configuration mode or shift configuration mode ("NO?" Response).
Peak hold remote control Cancellation	E	P	į,	l c	R LF															3	Y E S CR LF 5
Control of Cancellation	1	1	"	- 01	1								1 1							-	* Instructions are not accepted in the case of the configuration mode or shift configuration mode ("NO?" Response).

Functions/ Description		nsm 2			a 4	5	6	7	8	3 1	9	10	11	12	13	14	15	16	17	18	1 19) 2	0 2	21	22 :	23	Length	Received Data 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 Length
Max/Min/(Max-Min) Response •Checking max, min and (max-min) Values.	М	A		x	CR	LF																					3	M A X 5 0 0 . 0 CR LF 10 (Response with a MAX value.) M I N - 5 0 0 . 0 CR LF 10
																												(Response with a MIN value.) M - M 6 0 0 . 0 CR LF 10 (Response with a (MAX-MIN) value) * Batch response with delimiters. Each value right-justified zero suppressed response. Includes
Max/Min/(Max-Min) Clear	М				e M/			. CI	₹ L	F																	6	decimal point if any. Y E S CR LF CR LF S CR LF S CR LF S CR CRECE S CR LF S CR
		(Cle	ears	th	e MI	N va	lue.		1	F																	6	Y E S CR LF 5 (Received instructions) * Instructions are not accepted in the case of the configuration mode or shift configuration mode ("NO?" Response).
		(Cle	ears	th	e (M	AX-) vali		F																	6	Y E S CR LF 5 (Received instructions) * Instructions are not accepted in the case of the configuration mode or shift configuration mode ("NO?" Response).
• Range Response (except for thermometers)	R	N		G	CR	LF																					3	R A N G E 1 2 CR LF
•Range response (thermometer)	R	N		G	CR	LF																					3	(Response with the status of no range being selected.) * The response varies depending on the input unit or the status of range selection (8 characters max.). * The response varies depending on the input unit or the status of range selection (8 characters max.). * Response with the status of range KA being selected.) * R A N G E K B CR LF
																												Response with the status of range being selected. R A N Q E R CR LF
•Range configuration		(Se	ts 1	o r	ange	12.)	CI		F																	6	(Response with the status of range PA being selected.) R A N Q E J P A R F 9 (Response with the status of range JPA being selected.) Y E S 5 * Instructions are not accepted in the case of the configuration mode or shift configuration mode ("NO?" Response).
	R	(Se N (Se	ts 1	o r	ange	24. 2 2A.) A	CI	R L	F			1											1			6	Y E S R LF S S RESPECTIVE TO SET TO S
	R	(Se N (Se N (Se	ts 1	to ra G to ra G	ange ange ange	T.) JPI) CF P B.)	R LI	c	R L		inpu	ıt unit	ort	he ra	nge c	of int	teres	t.								5 7	* Instructions are not accepted in the case of the configuration mode or shift configuration mode ("NO?" Response). * Instructions are not accepted in the case of the configuration mode or shift configuration mode ("NO?" Response). * Instructions are not accepted in the case of the configuration mode or shift configuration mode ("NO?" Response). * Instructions are not accepted in the case of the configuration mode or shift configuration mode ("NO?" Response). * NO
Augranian fraguency reconnect																												(Response when a nonexistent range is set.)
Averaging frequency response •Response of setting value	A	٧		G	CR	LF																					3	A V G 1 CR LF 5 (Response with the status of the averaging frequency being once.) A V G 8 0 CR LF 6 (Response with the status of the averaging frequency being 80 times.)
Average frequency setting • Change of setting value	A					1/	2 /		3 / 1		20 /	40 /	80														5	Y E S OR LF 5 (Received instructions) * Instructions are not accepted in the case of the configuration mode or shift configuration mode ("NO?" Response).
Main	^	V (Se						cquer			time	s.)															6	Y E S CR LF 5 (Received instructions) * Instructions are not accepted in the case of the configuration mode or shift configuration mode ("NO?" Response).
Moving average calculation frequency response • Response of setting value	М	A	ľ	٧	GR	LF																					3	M A V O F F CR LF 7 (Response with the status of moving average calculation being set to OFF.) M A V O N = 4 CR LF 9 (Response with the status of the moving average calculation frequency being 4 times.)
Moving average calculation frequency setting • Change of setting value	м	A		٧				R LI		6/3	32																5	M A V O N = 1 6 CR LF 9 (Response with the status of the moving average calculation frequency being 16 times.) Y E S OR LF 5 (Received instructions)
	М	A (Se				(Ca	nce 6	ls mo	ving	aver	age		ulation cy to)											6	* Instructions are not accepted in the case of the configuration mode or shift configuration mode ("NO ?" Response). Y E S
Step wide response *Response of setting value	s	w		D	CR	LF																					3	S W D 1 CR LF 5
Step wide setting • Change of setting value	S	w		D		(Se	ts ti		ep w		to 1.		t) / 0	(100	ligit)												5	(Response with the status of the step width being 1.) Y E S CR LF (Received instructions) * Instructions are not accepted in the case of the configuration mode or shift configuration mode ("NO?" Response).
Communication function parameter response • Response of setting value					CR																						3	R S - 1 9 2 0 0 - 7 - E - 2 - C R / L F CR 21 (Baud rate - data length - parity - stop bit - delimiter, in that order.) * Parity is "E" for even numbers, "O" for odd numbers, and "N" for none. * Delimiter is "CR" for CR. "CR/LF" for CR+LF.
	R	Bau Ba Da Pa St	ud r aud ata arity op	rate rate leng / : E bit:	– D e : 9 gth :	ata I 600 7 / en) 2	engt / 48 8 /O (th - I 300 / odd)	Parity 240	y - 8 0 / 3	Stop 88400	bit -	- Delin 9200	niter,	in th			С	R	CF							17	Y E S CR LF 5 (Received instructions) * Instructions are not accepted in the case of the configuration mode or shift configuration mode ("NO?" Response). * The set value switches immediately after the response. However, the delimiter switches before the response.
Device ID response • Response of setting value	A	D		R	CR	LF																					3	A D R 0 1 or LF (Percent with the status of the desire D being (I)
Device ID setting •Change of setting value	A	D		R				CI 2-di																			6	(Response with the status of the device ID being 01.) Y E S OR LF 5 (Received instructions) * Instructions are not accepted in the case of the configuration mode or shift configuration mode ("NO?" Response).

Functions/ Description		nsm							; ,	140	1 44 1	10 1	0 1 4 4 1		0147	10 110	100104	100100		Received Data
·Analog output type response	A				R L) /	- 8	9	10	111	12 1	3 14	15	b 1/	18 19	20 21	22 23	Length 3	1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 Length A . O U T O F F CR LF 9 9
																				(Response with the status of the analog output type being OFF.)
																				A . O U T O - 1 CR LF 9 (Response with the status of the analog output type being 0-1 V.)
																				A . O U T 0 - 1 0 CR LF 10
																				(Response with the status of the analog output type being 0-10 V.) A . O U T 1 - 5 CR LF 9
																				(Response with the status of the analog output type being 1-5 V.) A . O U T 4 - 2 0 CR LF 10
																				(Response with the status of the analog output type being 4-20 mA.)
																				NO ? CR LF 5 (Response with the status of the analog output unit being not installed.)
·Analog output type setting	Α						F												7	YES OR LF 5
	A						ut typ					1	1 1	-	1 1	1	1 1		7	* Instructions are not accepted in the case of the configuration mode or shift configuration mode ("NO?" Response). Y E S CR LF 5
		(Set	ts th	e an	alog	outp	ut typ	e to	0-1 \	·.)										* Instructions are not accepted in the case of the configuration mode or shift configuration mode ("NO ?" Response).
	^						ut typ					ı	1 1	-		ı	1 1	1 1	8	Y E S CR LF 5 *Instructions are not accepted in the case of the configuration mode or shift configuration mode ("NO?" Response).
	Α	0	F	•	1	- ا	- 5	CF	₹ LF										7	YES CRLF 5
	A	(Set	ts th	e an	alog	outp	ut typ	e to	1-5 \ CF	(.) LF		-		-			1 1		8	* Instructions are not accepted in the case of the configuration mode or shift configuration mode ("NO ?" Response). Y E S CR LF 5
		(Set	ts th	e an	alog	outp	ut typ	e to	4-20	mA.)										* Instructions are not accepted in the case of the configuration mode or shift configuration mode ("NO ? " Response).
																				N O ? CR LF 5 (Response if product is not with analog output.)
8:31	<u> </u>		L	-	_	_	_	_	-	_		_	44		-	_				
Digital zero backup status response •Response of setting value	В	D	Z	CI	R L	F													3	B D Z O N CR LF 6
																				(Response with the status of digital zero backup being ON.) B D Z O F F CR LF 7
																				(Response with the status of digital zero backup being OFF.)
Digital zero backup status settings • Change of setting value	B	D	7				I CF												6	YES OR LF 5
- Orlange or setting value	-						up to												U	(Received instructions)
	B	D	7				F	CE											7	* Instructions are not accepted in the case of the configuration mode or shift configuration mode ("NO?" Response). Y E S CR LF 5
							cup to												,	(Received instructions)
																				* Instructions are not accepted in the case of the configuration mode or shift configuration mode ("NO ?" Response).
*Input selection response	I	S	E	L	. с	R L	F	\top				1							4	I S E L O . C CR LF 8
* Frequency input specification (15) only.	·																			(Response with the status of the input selection option being "open collector.") I S E L L G C CR LF 8
																				(Response with the status of the input selection option being "logic.")
																				I S E L M A G CR LF 8 (Response with the status of the input selection option being "magnet.")
																				N O ? CR LF 5
*Input selection setting	1	S	F	L) .	0	C										8	(Response when not frequency input specification (15).) Y E S
input selection setting		(Set	ts th	e inp	out s	elect	ion op	tion	to "c	pen c	lecto	.")							-	* Instructions are not accepted in the case of the configuration mode or shift configuration mode ("NO?" Response).
	I						_ G ion op					ı				ı			8	Y E S CR LF 5 * Instructions are not accepted in the case of the configuration mode or shift configuration mode ("NO ?" Response).
	I	S	E	L	-	١	ΛA	G	CF	LF									8	Y E S CR LF 5
		(Set	ts th	e inp	put s	elect	ion op	tion	to "n	agnet	.") ! !	1	1 1	-	1 1	1	1 1			* Instructions are not accepted in the case of the configuration mode or shift configuration mode ("NO?" Response). N O ? CR LF 5
																				(Response when not frequency input specification (15).)
Tracking zero response	-	_	╁	+	+	+	+	+	-	-		+	+	-	-	-	+			
Response of setting value	т	R	K	CI	R L	F													3	T R K O N T = 1 W = 1 CR LF 14
																				(Response with the status of the tracking zero is ON, tracking zero time is 1, and tracking zero width is 1.) T R K O N T = 1 0 W = 9 9 CR LF 16
																				(Response with the status of the tracking zero is ON, tracking zero time is 10, and tracking zero width is 99.)
																				T R K O F F CR LF 7 (Response with the status of the tracking zero function being set to OFF.)
Tracking zero setting																				
*Change of tracking zero time	Т	R	K		1	Γ =	* (the ri	ht for	2-digit.)	. !		l			7	Y E S CR LF 5 * Instructions are not accepted in the case of the configuration mode or shift configuration mode ("NO ?" Response).
· Change of tracking zero width	Т	R	K		٧	= ۲	- 9	9	CF	LF							1.1		8	YES CR LF 5
•Tracking zero OFF	т	R	K		1	r ! =	* (0~99	Foi		digits		quent co	omman	ids are le	ft-justif	fied.)		7	* Instructions are not accepted in the case of the configuration mode or shift configuration mode ("NO?" Response). Y E S CR LF 5
							o fun									:				* Instructions are not accepted in the case of the configuration mode or shift configuration mode ("NO ? " Response).
*Sensor power supply response	s	N	S	F	? C	R L	F	+	-	-	H	+	+	-		+	+		4	S N S R 1 0 CR LF 7
* Load cell input specification (17) only.			ľ	ľ		`` `													·	(Response with the status of sensor power supply being set to 10 V.)
																				S N S R 5 CR LF 6 (Response with the status of sensor power supply being set to 5 V.)
	s				₹		0												7	YES CRIF 5
		(Set	ts th	e se	nsor	powe	er sup	ply t	0 10	V.)		1	1 1	1	1 1	1	1 1			(Received instructions) * Instructions are not accepted in the case of the configuration mode or shift configuration mode ("NO?" Response).
	s			F			C F												6	YES CRLF 5
		(Set	ts th	e se	nsor	powe	er sup	ply t	5 V	.)		1	1 1	1	1 1	1	1 1			(Received instructions) * Instructions are not accepted in the case of the configuration mode or shift configuration mode ("NO?" Response).
Power-on delay time response																				
*Response of setting value	P	0	N	CI	R L	F													3	PONOFFCRLF 6 (Response with the status of the power-on delay function being set to OFF.)
																				P O N O N = 1 CR LF 7
																				(Response with the status of the power-on delay function being set to 1 sec.) PONONE 3 OCR LF 8
Demon on data (*																				(Response with the status of the power-on delay function being set to 30 sec.)
Power-on delay time setting *Change of setting value	Р	0	N		3	3 () CF	R LF											6	Y E S CR LF 5
					*	1~3	0 (Th	e abo	ve is	for 30	secor	ds.)								(Received instructions)
	P	0	N				R LF												5	* Instructions are not accepted in the case of the configuration mode or shift configuration mode ("NO ?" Response). Y E S CR LF 5
					*	Sets	the p	ower	on o	elay f	unction	to OF	F.				1 1			(Received instructions)
																				* Instructions are not accepted in the case of the configuration mode or shift configuration mode ("NO?" Response).
•Protection response	P	R	С	CI	R L	F							П						3	P R 0 0 F F CR LF 7
																				(Response with the status of the protection function being set to OFF.) PRO ONCRLF 6
- Donate aking and "	-	_					F												,	(Response with the status of the protection function being set to ON.)
Protection setting		(Set	ts th	e pr	otect	tion f	unctio	on to	OFF.		. !	1		1		1	1 1		7	Y E S CR LF 5 * Instructions are not accepted in the case of the configuration mode or shift configuration mode ("NO?" Response).
	P	R	C)	C) 1	CF	R LF											6	YES OR LF 5
		(Set	s th	e pr	otect	uon f	unctio	n to	UN.)	L	<u>_</u>									* Instructions are not accepted in the case of the configuration mode or shift configuration mode ("NO?" Response).
•Unit number response	U	N	C	CI	R L	F	Т	T	Т	T	П	T				T			3	I - 1 7 . O - 6 CR LF 8
* Unit No. cannot be changed.																				(Response with the status of the input unit being strain gauge measurement and the output unit being a combination of comparison output, analog output and RS-232C.)
																				I - 0 1 . 0 - 3 CR LF 8
																				(Response with the status of the input unit being DC voltage measurement (11 ranges) and the output unit being RS-232C.)
Key operation prohibition response		_				_													_	
*Response of key operation prohibited state	K				R L		ot ligh	nt up.	1	1		ı		1	1 1	ı			3	K E Y O N CR LF 6 (Response with the status of the key operation prohibition function being set to OFF.)
						- 1		-												* Key operation is not allowed.
																				K E Y O F F CR LF 7 (Response with the status of the key operation prohibition function being set to ON.)
*Key operation prohibition setting	K						CF						,I I			1			6	YES CR LF 5
											tion t	UFF	./	1		1				(Received instructions) ★ Instructions are not accepted in the case of the configuration mode or shift configuration mode ("NO?" Response).
	Κ						F					, ,							7	YES OR LF 5
		(Se	cs t	ne k	ey o	pera	cion p	prohi	bitio	Tunc	tion t	ON.)		1	1 1	1	1 1			(Received instructions) * Instructions are not accepted in the case of the configuration mode or shift configuration mode ("NO?" Response).

Functions/ Description	Transmit Data 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 Length	Received Data 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 Length
Comparator data response	C O M CR LF 3	S - H I 1 0 0 0 0 CR LF 10
	* The reading of the main unit changes to COM the moment it receives a COM command. N CR LF	(Response with the HI-side judgment value.) S - L O - 5 0 0 CR LF 10
	CR LF	S - L O - 5 O O CR LF
	N CR LF 1	H - H I 0 CR LF 10
	N CR LF 1	(Response with the HI-side hysteresis.) H - L 0 0 0 CR LF 10
		(Response with the LO-side hysteresis.)
	R CR LF 1 * The main unit returns to measurement operation upon an R command.	Y E S CR LF 5
	(Or returns to the HI-side judgment value if an N command is sent.)	
Comparator data setting * Set S-HI to 8000 and S-LO to 4000	C O M CR LF 3 * The reading of the main unit changes to COM the moment it receives a COM command.	S - H I 1 0 0 0 CR LF 10
(example).	8 0 0 0 CR LF 4	S - H I 8 0 0 0 CR LF 10
	(Sets the HI-side judgment value to 8000.)	
	N CR LF	S - L O 5 0 0 CR LF 10
	4 0 0 0 CR LF 4	S - L O 4 0 0 0 CR LF 10
	(Sets the LO-side judgment value to 4000.) R CR LF 1	Y E S CR LF 5
	* If an R command is sent after setting required data, the main unit saves data provided up to that moment	
	and then returns to measurement operation.	E r r o r CR LF 6 (Response when a value that does not meet the setting conditions is input.)
Scaling data response	 	(Response when a value that does not meet the setting conditions is input.)
·Transition to scaling data settings	M E T CR LF	F S C 9 9 9 9 0 R LF 10
		(Response with the set value of full-scale reading value is 9999.) The reading of the main unit changes to MET the moment it receives an MET command.
		* Instructions are not accepted in the case of the configuration mode or shift configuration mode ("NO?" Response).
 Response of the setting value of the next setting item. 	N CR LF 1	F I N 9 9 9 CR LF 10 10 (Response with the set value of full-scale input value is 9999.)
* The response changes each time N is sent.		
	N CR LF 1	0 F S 0 CR LF 10
	N CR LF	(Response with the offset reading value is 0.) O I N O CR LF 10
		(Response with the offset input value is 0.)
	N CR LF 1 (If it is not a frequency measurement model, proceed to the next item.)	P S 2 . 0 0 0 CR LF 11
	N CR LF 1	P P R 1 0 0 CR LF 10
	(If it is not a frequency measurement model, proceed to the next item.) N CR LF 1	(Response with the set value of frequency divider is 10.0) D
		(Response with the digital limiter HI value is 9999.)
	N CR LF	D L L O - 9 9 9 9 0 0R LF 10
	N CR LF	(Response with the digital limiter LO value is -9999.) A O H I 9 9 9 9 CR LF 10 10
	(If it is not an analog output model, proceed to the next item.)	(Response with analog output HI value is 9999)
	N CR LF 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	A O L O O CR LF
		Each value right-justified zero suppressed response. Includes decimal point if any.
	N CR LF 1	D E P 4 CR LF 6 6 (Response for no decimal point position. Decimal point position is 4th digit = 3, 3rd digit = 2, 2nd digit = 1, 1st digit = 0.)
	R CR LF	Y E S CR LF 5
	The main unit returns to measurement operation upon an R command (or returns to the response with the	(Return to measurement operation.)
Scaling data setting	full-scale reading if an N command is sent.)	
• Set FSC to 8000 and OFS to 20 (example)	M E T CR LF 3	F S C 9 9 9 9 0 CR LF 10
•Full-scale reading value setting	8 0 0 0 CR LF 4	(Response with the set value of full-scale reading value is 9999.) F S C 8 0 0 0 CR LF 10 10 10 10 10 10 10 1
* Only when the current setting item is a	*-9999~9999	(Response of the set value.)
full-scale reading value.	* For fewer digits, left-justify the following commands. Decimal points are not included.	
* Sending N will move on to the next item.	(The same applies to other parameters.) N CR LF 1	F I N 9 9 9 9 0R LF 10
		(Response with the set value of full-scale input value is 9999.)
	N CR LF	O F S 0 CR LF 10 (Response with the offset reading value is 0.)
·Offset reading value setting	2 0 CR LF 2	0 F S 2 0 CR LF 10
* Only when the current setting item is an offset reading value.	R CR LF	(Response of the set value.) Y E S CR LF 5
an onset reading value.	* If an R command is sent after setting required data, the main unit saves data provided up to that moment	(Return to measurement operation.)
	and then returns to measurement operation.	Error CRLF 6
Linearization function status response		(Response when a value outside the setpoint range is input.)
·Response of setting value	L I N CR LF 3	L I N O F F CR LF 7
		(Response with linearize function is OFF.)
		(Response with linearize function is ON.)
		L I N C L R CR LF 7 (Response with the status of the linearization function being cleared.)
Linearize function status setting	L 1 N O F f CR LF 7	YES CR LF 5
· Change of setting value	(Sets the linearization function to an OFF status.)	(Received instructions) * Instructions are not accepted in the case of the configuration mode or shift configuration mode ("NO?" Response).
	L I N O N CR LF	* Instructions are not accepted in the case of the configuration mode or shift configuration mode (NO ? Response). Y E S CR LF 5
	(Sets the linearization function to an ON status.)	(Received instructions)
	L I N C L R CR LF	* Instructions are not accepted in the case of the configuration mode or shift configuration mode ("NO ?" Response). Y E S CR LF 5
	(Sets the linearization function to a cleared status.)	(Received instructions)
		* Instructions are not accepted in the case of the configuration mode or shift configuration mode ("NO ?" Response). N O ? CR LF 5
		(Response with the status of the linearization function being cleared.)
		* Since the linearization data are all cleared when the linearization function is cleared, the main unit does not accept either a LIN ON or LIN OFF command.
		does not accept either a LIN ON or LIN OFF command. Set the linearization function status after setting the linearization data again.
Response for number of linearization		
correction data items Response of setting value	L N O OR LF	L N O 0 0 GR LF 6
pondo or dottarig value		(Response with the status of the linearization function being cleared.)
		L N O 0 2 CR LF 6
Setting for number of linearization		(Response with the status of the number of linearization correction data items being 02.)
correction data items		
*Change of setting value	L N O 1 6 CR LF 6	Y E S
	(Sets the number of linearization correction data items to 16.)	* Instructions are not accepted in the case of the configuration mode or shift configuration mode ("NO ? " Response).
		E r r o r CR LF 6 6 (Response when linearization data is not correctly set.)
		* Instructions are not accepted in the case of the configuration mode or shift configuration mode ("NO?" Response).
		* Set the number of linearization correction data items after setting linearization data.

Functions/ Description	Transmit Data 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 Length	Received Data 1
Linearization data response		
•Transition to linearized data response.	L N D 0 1 CR LF 6	L N D 0 1 I = 0 0 CR LF 14 (Response with the input value of linearization correction data N-01 is 0.)
		The reading of the main unit changes to LINE the moment it receives an LND command. * Instructions are not accepted in the case of the configuration mode or shift configuration mode ("NO?" Response).
•Response of the setting value of the		If the number of linearization points is not set (00), "NO ?" Response.
next setting item. * The response changes each time N is sent.	N CR LF	L N D 0 1 0 = 0 0 CR LF 14 (Response with the output value of linearization correction data N-01 is 0.)
* The response changes each unlervis seric	N CR LF	L N D 1 6 1 = 9 9 9 9 CR LF 14
	N CR LF	(Response with the input value of linearization correction data N=16 is 9999.) L N D 1 6 O = - 9 9 9 9 0 CR LF 1 14
		(Response with the output value of linearization correction data N=16 is =9999.) * Each value right-justified zero suppressed response. Decimal points are not included.
	R CR LF 1 * The main unit returns to measurement operation upon an R command.	Y E S CR LF
	(In case of N command, return to the response of N-01 input value.)	
Linearization data setting	L N D 0 1 CR LF 6 * Setting can be made from any of the data items 01 to 16.	L N D 0 1 I = 0 0 CR LF 14 (Response with the set value of input value of linearization data N-01 is 0.)
• Set the input value of N-01 to -1000	- 1 0 0 0 CR LF 5	L N D 0 1 1 = - 1 0 0 0 CR LF 14
*Only when the current setting item is the N-01 input value.	* For fewer digits, left-justify the following commands. Decimal points are not included. (The same applies to other parameters.)	(Response of the set value.)
* Sending N will move on to the next item.	N CR LF	L N D 0 1 0 = 0 CR LF 14 (Response with the set value of the output value of linearization data N-01 is 0.)
*Set the output value of N=01 to =900 *Only when the current setting item is	- 9 0 0 CR LF 4	L N D 0 1 0 = - 9 0 0 CR LF 14 (Response of the set value.)
the N-01 output value.	N CR LF 1	L N D 0 2 I = 0 CR LF 14 (Response with the set value of the input value of linearization data N=02 is 0).
*Set the input value of N-02 to -500 * Only when the current setting item is	- 5 0 0 0 CR LF 4	L N D 0 2 1 = - 5 0 0 CR LF 14 (Response of the set value.)
the N-02 input value.	N CR LF	L N D 0 2 O = 0 CR LF 14
•Set the output value of N-02 to -600	- 6 0 0 CR LF 4	L N D 0 2 0 = - 6 0 0 CR LF 14
	R CR LF	(Response of the set value.) Y E S
* Only when the current setting item is an offset reading value.	* If an R command is sent after setting required data, the main unit saves data provided up to that moment and then returns to measurement operation.	(Return to measurement operation.)
		E r r o r CR LF 6 (Response when a value outside the setpoint range is input.)
Calibration data response Load cell input specification (17) only.	C A L 2 CR LF 4 * The reading of the main unit changes to CAL2 the moment it receives a CAL2 command.	Z E R O O O O O O M V / V CR LF 15 (Response with a zero-input value.)
	J CR LF 1	S P I N 2 . 0 0 0 m V / V CR LF 15 (Response with a span input value.)
	N CR LF	S P A N 9 0 0 0 CR LF 10
	R CR LF	(Response with a span reading.) Y E S CR LF 5
	* The main unit returns to measurement operation upon an R command. (In case of N command, return to the zero-input value response.)	
Calibration data setting	C A L 1 CR LF	Z E R O CR LF 4
(Calibration with actual load)	N CR LF	Z E R O CR LF 4
	(Executes zero calibration.) * The main unit moves to the setting of a span reading without performing zero calibration if a J command is sent.	S P A N 9 0 0 0 CR LF 10 (Response when zero calibration is executed correctly, and a transition is made to span calibration.)
		E r r o r X CR LF
		* Apply an input signal within the zero-adjustment range (-0.3 to less than 1 mV/V) and resend the N command.
	5 0 0 0 0 CR LF 4 (Sets the span reading to 5000.)	S P A N 5 0 0 0 0 CR LF 10
	N OR LF	Y E S CR LF 5 5 (Response when span calibration is executed correctly.)
		* The main unit automatically returns to measurement operation when span calibration is executed correctly. E r r X CR LF
		S P A N 9 0 0 0 0 R LF 10 (Response when an input signal that is outside the zero-adjustment range or contains a gain error is applied.)
		* The main unit returns to the setting of a span reading. * Check the applied input signal level or span reading and set the calibration data again.
	R CR LF	YES CR LF 5
	If an R command is sent during setting, the main unit saves data provided up to that moment and then returns to measurement operation (span reading is not saved, however).	
· Calibration data setting	C A L 2 CR LF 4	Z E R O . 0 0 0 m V / V CR LF 15
(Equivalent calibration)	0 0 0 4 CR LF 4	Z E R O 0 . 0 0 4 m V / V CR LF 15
	(Sets the zero-input value to 0.004 mV/V.) N	S P I N 2 . 0 0 0 m V / V CR LF 15
	(Executes zero calibration.)	(Response when zero calibration is executed correctly, and a transition is made to span input value setting.) E r r o r X CR LF 7
		Z E R O O . O O O m V / V CR LF
	1 5 0 2 CR LF 4	* Resend a value within the zero-adjustment range (-0.3 to less than 1 mV/V). S P I N 1 . 5 0 2 m V / V CR LF . 15
	(Sets the span input value to 1.502 mV/V.) N OR LF 1 1 1 1 1 1 1 1 1	S P A N 9 0 0 0 cr LF 10
	5 0 0 0 cr LF	
	(Sets the span reading to 5000.)	
	R CR LF 1 (Executes span calibration.)	Y E S CR LF 5 (Response when span calibration is executed correctly.)
		* The main unit automatically returns to measurement operation when span calibration is executed correctly.) E r r o r X CR LF 7
		S P I N 2 . 0 0 0 m V / V CR LF 15 (Response when a value that contains a gain error or is outside the range is set.)
		* The main unit returns to span input value setting.
Shift data response	S H F CR LF	S H F 1 2 3 4 CR LF 9
		S H F 1 2 CR LF 9
		S H F - 1 2 3 4 CR LF 9
		* If there is no decimal point, 9 digits are fixed. S H F 1 2 . 3 4 CR LF 10
		S H F - 1 . 2 3 4 CR LF
		S H F - 0 . 0 0 1 CR LF
		* If there is decimal point, 10 digits are fixed.
Shift data setting	S H F 1 2 3 4 CR LF 8	YES CR LH 5
	S H F - 1 2 3 4 CR LF 9	YES CR LF 5
	S H F 1 2 CR LF 6	Y E S CR LF 5
	S H F - 1 CR LF 6	Y E S OR LF 5
[

Functions/ Description	Tra	nsmi	t Da	ita																						Rec	eived	Dat	а																							
·	1	2	3	4	5	6	7	7	8 !) 10) 11	12	13	14	15	16	17	18	19	2	0 2	2	2 23	Le	ngth	1	2	3	4	5	6	7	7	8	9	10	0 1	11	12	13	14	- 1	5 1	6	17	18	19	2	0 2	1 2	22	Length
Low cut data response	L	С	Т	CF	t LF																				3	L		T T			2	1		2	CF	L	F															8
																										L	C	Т	is no	1	2			3	4	C		LF														9
																											C * If t		is de		al po							LF														9
Low cut data setting	L	С	т		1	2		3	4 c	R LI	-														8		E				ľ	L	- [5
	L	С	т		1	2	С	R L	_F																6	Υ	E	s			CF	L	F																			5
	L	С	Т		1	CI	R L	F																	5	Υ	E	s			CF	L	F																			5
Common Responses																											Ε				CF																					5
																										N	(Norr O (Resi		?		CF	L	F) ms	max					ļ	į					ļ	-	ļ		5
																										Ε	R (Res	r	0	r		С	R	LF		rang	ge or	r dat	a th	at do	oes r	not r	neet	the	sett	ing o	conc	dition	ıs.)	į		6
*Response in case of data failure in the internal memory.																											A (Resi				L							С	0	N	D	С	R L	F								14
* Under normal conditions, this response is made only once.																										D	* Set	the T	con	ditio	n dat	a ag	ain.	S	Т				0	М	CR	ı Lu	-					1		ı		13
																										D	* Set	the T	com A	para	tor o	lata	aga)	in. S	т				E	т	CF	: L	-	i	i				i	i		13
																											(Resp * Set							ata f	tailu	re.)	1	ı			1	1	1	1			1	1		1		

watanabe

Watanabe Electric Industry Co.,Ltd.

7150-0001 6-16-19 Jingumae, Shibuya-ku, Tokyo

TEL: +81-3-3400-6147 FAX: +81-3-3400-3156

HP: https://www.watanabe-electric.co.jp